



ELEVATORS MOTORS CORPORATION

- ◆ Indicadores progresivos de carga.
- ◆ Señalización visual progresiva y acústica de sobrecarga.
- ◆ Conexión a 2 hilos sin polaridad.

-
- ◆ *Progressive indicator of the load.*
 - ◆ *Visual and Sound indicator of the overload.*
 - ◆ *2 threads connection without polarity.*



MB-D



MB-R




Display de Cabina

Indicador de carga en la cabina/Cabin load weight indicator

Dimensiones en mm./Dimensions in mm.

Conexión eléctrica/
Electrical connection



Nota: Para otros diseños y medidas especiales, póngase en contacto con nuestro departamento comercial.

Note: For fabrication of special display to the clients measure, Please contact our Commercial Department.

Características generales

- ◆ Indicador progresivo de la carga.
- ◆ Señalización visual de completo.
- ◆ Señalización visual y sonora de sobrepeso.
- ◆ Frontal en acero inoxidable.
- ◆ Montaje en panel, enrasado o con marco.
- ◆ Conexión a 2 hilos sin polaridad.

General characteristic

- ◆ Progressive indicator of the load.
- ◆ Visual indicator of the full load.
- ◆ Visual and Sound indicator of the overload.
- ◆ Front made of stainless steel.
- ◆ Installation in panel evened or with mark.
- ◆ 2 threads connection without polarity.

ELEVATORS MOTORS CORPORATION

80 Carolyn Boulevard. Farmingdale, NY 11735-1525

Phone (631) 293-4220. Fax (631) 293-2714. E-mail: info@elevatormotors.com